

# P16 - 2500

## START BOOSTER

12V

AGM

### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.

### ON/OFF SWITCH

This model is fitted with an easy to use on off switch for maximum safety.



**Model**  
P16-2500

**Volts**  
12V

**Peak Amps (A)**  
2500A

**# Of Batteries**  
1

**Location of Fuse**  
Clamp

**Fuse (A)**  
500

**Dimensions (cm)**  
39x31x22

**Cable Ø (mm2)**  
25

**Cable Length (cm)**  
162

**Unit Weight (KG)**  
12

**Charger Voltage (V)**  
14.4

**Charger Amps (A)**  
3

**Vehicle types**



**LEMANIA ENERGY**  
Switzerland

# P16 - 3100

## START BOOSTER

12V



### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.

### ON/OFF SWITCH

This model is fitted with an easy to use on off switch for maximum safety.



**Model**  
P16-3100

**Volts**  
12V

**Peak Amps (A)**  
3100A

**# Of Batteries**  
1

**Location of Fuse**  
Clamp

**Fuse (A)**  
500

**Dimensions (cm)**  
39x31x22

**Cable Ø (mm2)**  
25

**Cable Length (cm)**  
162

**Unit Weight (KG)**  
13.5

**Charger Voltage (V)**  
14.4

**Charger Amps (A)**  
3

**Vehicle types**



**LEMANIA ENERGY**  
Switzerland +

[www.lemania-energy.com](http://www.lemania-energy.com)