

# P1 - 25000


## START BOOSTER

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



Car SUV  
MPV 4WD



Motorcycle

12V

AGM

**Model**  
P1-2500

**Volts**  
12V

**Peak Amps (A)**  
2500A

**Starting Amps (A)**  
850A

**# Of Batteries**  
1

**Location of Fuse**  
Optional

**Fuse (A)**  
Optional

**Dimensions (cm)**  
32x10x30

**Cable Dimenter (mm2)**  
25

**Cable Length (cm)**  
75

**Unit Weight (KG)**  
11.3

**Charger Voltage (V)**  
230

**Charger Amps (A)**  
1.2

### ULTRA HIGH GRADE CABLES

Full copper woven cables are extremely durable and allow for very limited losses providing the highest starting power.

### RIBBED ABS CHASSIS

Reinforced internal structure provides strength and durability making a dependable chassis.



**LEMANIA ENERGY**  
Switzerland +

# P1 - 3100

## START BOOSTER

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



Car SUV  
MPV 4WD



Motorcycle

12V

AGM

**Model**  
P1-3100

**Volts**  
12V

**Peak Amps (A)**  
3100A

**Starting Amps (A)**  
1170A

**# Of Batteries**  
1

**Location of Fuse**  
Optional

**Fuse (A)**  
Optional

**Dimensions (cm)**  
32x10x30

**Cable Dimenter (mm2)**  
25

**Cable Length (cm)**  
75

**Unit Weight (KG)**  
11.3

**Charger Voltage (V)**  
230

**Charger Amps (A)**  
1.2

### ULTRA HIGH GRADE CABLES

Full copper woven cables are extremely durable and allow for very limited losses providing the highest starting power.

### RIBBED ABS CHASSIS

Reinforced internal structure provides strength and durability making a dependable chassis.



**LEMANIA ENERGY**  
Switzerland +





**12V**  
**24V**







6V

12V

24V

AGRICULTURE







**HEAVY DUTY**

