P4-ST-6200 START TRUCK

LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternatorof a vehicle.

INBUILT SAFTEY FUSE

Pure brass clamps with braided connection protected by a saftey fuse.

2-24V CONNECTORS

Easy to use switch allows the booster to be changed from 12V to 24V.



12V

24V

AGM









LEMANIAENER

Switzerland

www.lemania-energy.com