# **P12-TR-2050**

START TRUCK

### **START TRUCK**



#### AIR TANK\*

Equiped with a 13 Bar pressure tank professionals of incorrect terminal connections.

Model P12-TR-2050 Volts 12/24 Peak Amps (A) 2050/1025 # Of Batteries\*

Location of Fuse

**Fuse (A)** 1000

Dimensions (cm) 152x64x62

**Cable** Ø (mm2) 70

Cable Length (cm) 245

Unit Weight (KG)

Charger Voltage (V) 14.4

Charger Amps (A)

Vehicle types

### www.lemania-energy.com



#### DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.

#### **REVERSE POLARITY ALARM**

This audible and visual alert informs professionals of incorrect terminal connections.







#### **4 WHEEL TROLLEY SETUR**

This 4 wheeled setup allows the booster to be moved easily from vehicule to vehicule saving time and energy.



\*optional air tank \*possibility of fitting 6 batteries

## P12-TR-3050

START TRUCK

## START TRUCK



#### AIR TANK\*

Equiped with a 13 Bar pressure tank professionals of incorrect terminal connections.

**Model** P12-TR-3050

Volts 12/24 Peak Amps (A) 3050/1525

# Of Batteries\* 2 Location of Fuse

Case Fuse (A) 1000

Dimensions (cm) 152x64x62

Cable Ø (mm2) 70

Cable Length (cm) 245 Unit Weight (KG)

70

**Charger Voltage (V)** 14.4

Charger Amps (A)

Vehicle types

www.lemania-energy.com





This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.

#### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.







#### 4 WHEEL TROLLEY SETUP

This 4 wheeled setup allows the booster to be moved easily from vehicule to vehicule saving time and energy.



