# P15-TR-5000

## START TRUCK





### DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.

### 12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.

### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.







Model P15-TR-5000

**Volts** 12/24

Peak Amps (A) 5000/2500

# Of Batteries

**Location of Fuse** Clamp

Fuse (A) 500

Dimensions (cm) 52x37x36

Cable Ø (mm2)

Cable Length (cm)

Unit Weight (KG) 27

Charger Voltage (V)

Charger Amps (A)







