6-TR-6200

START TRUCK

12V 24V



This audible and visual alert informs professionals of incorrect terminal connections.

Easy to use switch allows the booster to be changed from

12V to 24V.

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.











Volts 12/24

Peak Amps (A) 6200/3100

Of Batteries

Location of Fuse

Fuse (A) 500

Dimensions (cm)

Cable Ø (mm2)

Cable Length (cm)

Unit Weight (KG)

Charger Voltage (V)

Charger Amps (A)

Vehicle types





