# P21-ST-50000**START BOOSTER**

Pure brass clamps with braided connection protected by a saftey fuse.



This audible and visual alert informs professionals of incorrect terminal connections.

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.



# P21-ST-6400 <u>START BOOSTER</u>

### INBUILT SAFTEY FUSE

Pure brass clamps with braided connection protected by a saftey fuse.



## EVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

### DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.





Easy to use switch allows the booster to be changed from 12V to 24V.

**Model** P21-ST-6400

**Volts** 12V/24<u>V</u>

**Peak Amps (A)** 6400/3200

# Of Batteries

Location of Fuse

Fuse (A) 500

Dimensions (cm) 41x34x24

**Cable** Ø **(mm2)** 50

Cable reach (cm) 150

Unit Weight (KG)

Charger Voltage (V) 14.4

Charger Amps (A)

Vehicle types





www.lemania-energy.com

ا **بابر بابر جم حم خد م**د