# P21-TR-5000

## **START TRUCK**





### 12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.



#### REVERSE POLARITY ALARM

This audible and visual alert — informs professionals of incorrect terminal connections.



### DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.



Model P21-TR-5000

Volts

Peak Amps (A) 5000/2500

# Of Batteries

**Location of Fuse** Clamp

Fuse (A) 500

Dimensions (cm) 49x34x29

**Cable** Ø (mm2) 50

Cable reach (cm)

Unit Weight (KG)

Charger Voltage (V)

Charger Amps (A)

-----Vehicle types





