26-TR-5000



START TRUCK





This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.

Easily move the booster to where it is needed using the trolley wheels and handle.



Easy to use switch allows the booster to be changed from 12V to 24V.

This audible and visual alert informs professionals of incorrect terminal connections.

Model P26-TR-5000

Peak Amps (A) 5000/2500

Of Batteries

Cable Length (cm) 185

Charger Voltage (V)

Charger Amps (A)

Vehicle types



LEMANIA

START TRUCK

HEAVY DUTY 12V/24V



SWISS + MADE



Volts 12/24

Locaiton of Fuse Clamp

Fuse (A) 500

Dimensions (cm) 53x43x31

Unit Weight (KG) 25

www.lemania-energy.com

P26-TR-6400



START TRUCK





DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.


TROLLEY SYSTEM

Easily move the booster to where it is needed using the trolley wheels and handle.



12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.



This audible and visual alert informs professionals of incorrect terminal connections.



Locaiton of Fuse Clamp

Model P26-TR-22

Volts 12/24

Fuse (A) 500

Peak Amps (A) 6400/3200 # Of Batteries

_____ Dimensions (cm) 53x43x31

53x43x31 **Cable** Ø (mm2) 50

Cable Length (cm)

—— Unit Weight (KG)

Charger Voltage (V)

Charger Amps (A)

Vehicle types





