EXART BOOSTER 12V

.....

12V

LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



Volts 12V

Peak Amps (A) 2500A

Of Batteries

Location of Fuse Optional

Fuse (A) Optional

Dimensions (cm) 33x35x25

Cable Ø **(mm2)** 25

Cable Length (cm)

Unit Weight (KG) 10

Charger Voltage (V) 14.4

Charger Amps (A) 3

Vehicle types



www.lemania-energy.com

Full copper woven cables are

51ART BOOSTER

extremely durable and allow for very limited losses providing the highest starting power.



RIBBED ABS CHASSIS

SWISS

Reinforced internal structure provides strength and durability making a dependable chassis.



DO J START BOOSTER

.....

12V

LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



Volts 12V

Peak Amps (A) 3100

Of Batteries

Location of Fuse Optional

Fuse (A) Optional

Dimensions (cm) 33x35x25

Cable Ø **(mm2)** 25

Cable Length (cm)

Unit Weight (KC)

Charger Voltage (V) 14.4

Charger Amps (A)

Vehicle types



ULTRA HIGH GRADE CABLES

START BOOSTER

Full copper woven cables are extremely durable and allow for very limited losses providing the highest starting power.

RIBBED ABS CHASSIS

LEMANIAENERG

SWISS

Reinforced internal structure provides strength and durability making a dependable chassis.

Switzerland





0