# P = T R = 6200

## **START TRUCK**



The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.

This audible and visual alert informs professionals of incorrect terminal connections.

Easy to use switch allows the booster to be changed from 12V to 24V.

Easily move the booster to where it is needed using the trolley wheels and handle.



SWISS E 12/24V


INTEGRA

/01/0923

and the second

TEST

FUSE



Location of Fuse

Clamp **Fuse (A)** 500

Dimensions (cm) 38x35x27 **Cable Ø (mm2)** 50

Cable Length (cm) 165

Unit Weight (KG)

Charger Voltage (V)

Charger Amps (A)

Vehicle types





www.lemania-energy.com

\* \* <del>\* \* \* \* \* \* \* \* \* \* \* \* \* \* \*</del> \*