

# P25 - 1600

12V

AGM

## START BOOSTER

### INBUILT SAFETY FUSE

Pure brass clamps with braided connection protected by a safety fuse.

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.

### USB OUTPUT

**Model**  
P25-1600

**Volts**  
12V

**Peak Amps (A)**  
1600A

**# Of Batteries**  
1

**Location of Fuse**  
-

**Fuse (A)**  
-

**Dimensions (cm)**  
12.5x12.2x29


**Cable Ø (mm2)**  
25

**Cable Length (cm)**  
52

**Unit Weight (KG)**  
6.7

**Charger Voltage (V)**  
14.4

**Charger Amps (A)**  
3

**Vehicle types**  


### FUSE IN CLAMP

### FORMFACTOR CASE

This form-factor case is highly portable and easily stored.

