H2 - TR - 1500



PROCAP HYBRID START BOOSTER



to quickly see the voltage available and to test the alternator of a vehicle.

informs professionals of incorrect terminal connections.

Easily move the booster to where it is needed using the trolley wheels and handle.

Easy to use switch allows the booster to be changed from 12V to 24V.







— Peak Amps (A)

Fuse (A) 500

Cable Ø **(mm2)** 50

Cable reach (cm)

Charger Voltage (V)

Charger Amps (A)

Vehicule types






LEMANIA

START TRUCK

HEAVY DUT





This display allows professionals

This audible and visual alert



























