

# P20-ST-5000

## START TRUCK

12V  
24V

AGM

### 12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.

### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



<b>Model</b>	P20-ST-5000
<b>Volts</b>	12/24
<b>Peak Amps (A)</b>	5000/2500
<b># Of Batteries</b>	2
<b>Location of Fuse</b>	Clamp
<b>Fuse (A)</b>	500
<b>Dimensions (cm)</b>	41x39x20
<b>Cable Ø (mm2)</b>	50
<b>Cable Length (cm)</b>	172
<b>Unit Weight (KG)</b>	22.5
<b>Charger Voltage (V)</b>	14.4
<b>Charger Amps (A)</b>	3
<b>Vehicle types</b>	

\*voltmeter in option

### RIBBED ABS CHASSIS

Reinforced internal structure provides strength and durability making a dependable chassis.



**LEMANIAENERGY**  
Switzerland +

# P20-ST-6200

## START TRUCK

12V  
24V

AGM

### 12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.

### REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

### LED CHARGE INDICATOR

The test button allows users to easily check the charge level of the booster and test the alternator of a vehicle.



<b>Model</b>	P20-ST-6200
<b>Volts</b>	12/24
<b>Peak Amps (A)</b>	6200/3100
<b># Of Batteries</b>	2
<b>Location of Fuse</b>	Clamp
<b>Fuse (A)</b>	500
<b>Dimensions (cm)</b>	41x39x20
<b>Cable Ø (mm2)</b>	50
<b>Cable Length (cm)</b>	172
<b>Unit Weight (KG)</b>	25.5
<b>Charger Voltage (V)</b>	14.4
<b>Charger Amps (A)</b>	3

\*voltmeter in option

### RIBBED ABS CHASSIS

Reinforced internal structure provides strength and durability making a dependable chassis.



**LEMANIA ENERGY**  
Switzerland +